INDEX

www.midlandeurope.com

# MIDLAND BTNEXT PRO

**Dual core intercom system**

*Midland BTNEXT PRO is an intercom system solution with Dual Bluetooth Core for confe-rence communication and real background stereo audio. The design is very slim and aerody-namic, all the main functions are easy to operate thanks to the three big buttons placed on the front of the unit. Midland BTNEXT PRO is fixed on the helmet using the adhesive plate or the screw mounting clamp. Thanks to the audio kit with ultra slim speakers you can enjoy high quality stereo music while riding.*

## Main features

› Dual Bluetooth core system.
› Intercom "one to one" up to 1 mile (1.6 Km) distance.
› Conference up to 8 people (4 couples)
› Connect up to 6 people for "one to one" intercom communication
› Universal Intercom Talk2All features to connect other brand intercom
› FM Radio Stereo with RDS
› Music Share (Driver and Passenger)
› Connect your phone to receive and place phone call and listen to stereo music
› Support for 2 phones
› Connect your GPS for voice street indications
› Connection for PMR466 radio with internal or external Bluetooth
› AUX wired connection for MP3 player (optional cable)
› Setup and Firmware update via USB connection to a PC

**Midland BTNEXT PRO is available in two versions:**

› Single Midland BTNEXT PRO Intercom kit with one unit only
› Twin Midland BTNEXT PRO Intercom kit with with two units
Depending on the model purchased, the package contains the following parts:

**Midland BTNEXT PRO single**

› 1 BTNEXT PRO communication unit
› 1 Slide-in mounting kit with two stereo speakers

› 1 microphone with boom and 1 wired microphone
› 1 plate with bi-adhesive strip to fix the unit onto the helmet
› 1 plate with screw to fix the unit onto the helmet
› 1 micro USB wall-mounting power supply

**Midland BTNEXT PRO Twin**

› 2 BTNEXT PRO communication units
› 2 Slide-in mounting kit with two stereo speakers
› 2 microphones with boom and 2 wired microphones
› 2 plates with bi-adhesive strip to fix the unit onto the helmet
› 2 plates with screw to fix the unit onto the helmet
› 1 micro USB wall-mounting power supply with double plug
*The units included in the TWIN kit are already paired on Middle button and can therefore be immediately used in Intercom mode.*

## Technical specifications of Midland Midland BTNEXT PRO

**General:**
› Bluetooth ver. 4.2 Stereo (Handsfree/A2DP/AVRCP protocol)
› Dual Bluetooth core for real Stereo Background
› AGC system automatically controls the volume in relation to background noise
› Voice (VOX) or manual communications activation
› Manual controls to enable: telephone, intercom, FM Radio and wire connection
› Fully waterproof
› Lithium battery with 35 hours talk time
› Recharge time: app. 2 hours

**Bluetooth connections:**

With identical device for Rider to Pillion or Bike-to-Bike Intercom mode, up to a ma-ximum distance range of 1.6Km without obstructions and interferences (the riders must be always in sight).

**Bluetooth devices:**
› Mobile phone with MP3 player Stereo (A2DP protocol) and GPS navigator
› PMR446 transceivers (with built-in or external Bluetooth connection) for group bike-to-bike communications

Wire connections:

› For stereo audio input like iPod/MP3 player (with optional cable)
*Attention: Midland BTNEXT PRO is designed to withstand rain and water. However, if it is raining, always verify that the rubber cap protecting the recharging sockets is fully fitted.*

## Charging batteries

*Attention: Make sure that the unit is fully charged before use. Allow at least 3 hours for a full charge before using the unit for the first time.*

Charge the unit by inserting the wall-charger into the charging socket (lift the rubber cover to insert the plug). The red LED on the unit will start flashing when charging begins. Allow the headset to charge until the unit stops flashing and the blue LED turns on.
When the charge is complete (the red LED is not flashing), release the headset from the charger. Normally, after the first time, it takes 2 hours for a full charge.

*Attention: every time the micro USB recharging plug is inserted (or detached), the device is automatically turned off. To use it while it is in charge, you should turn the device on with the plug already inserted.*

## Unit and fixing system description

### BTNEXT PRO description
The BTNEXT PRO has five buttons on the front; the main three big button are multi functions buttons: the Forward (on the left), the middle button and the Backward (on the right), the two squared buttons are the Volume + and Volume -.

Volume -    Volume +



Forward        Middle            Backward

### Description of the wired connections
On the bottom of the unit you can find the **Charger jack** that enables to recharge the unit using a standard microUSB power supply
**The same micro USB charger plug** can be used to connect an audio source, like a stereo iPod/MP3 player;

*Attention: you need an optional AUX cable not included in the box.*



Charger plug

### Description of the audio kit
The audio system includes two ultra-flat stereo speakers and two interchangeable microphones, which are both supplied with a bracket and wired connection. The mini connector on the microphone allows you to choose the microphone that best suits the helmet you are using.

### Fixing the stereo speakers
The two stereo speakers have a Velcro/adhesive strip that aids their fixing into your helmet. Beware not to keep the volume too high, you must always be able to listen to the traffic sound.

UK

## Fixing the microphone

### Boom Microphone

Place the section with the Velcro/adhesive strip between the padding and the rigid cover of the helmet, so that the microphone is correctly positioned in front of your mouth and that the white symbol is facing your mouth. This type of microphone is suited for Open Faced and Flip Front helmets.



### Wired microphone

Using the Velcro/adhesive strip, place the microphone inside the helmet in front of your mouth. This type of microphone is more suited for Full Faced helmets. The mini connector on the microphone allows you choose the microphone that best suits the helmet you are using.

### Description of the Slide-in mounting kit

The Midland BTNext PRO can be fixed onto the helmet, installing the slide-in mounting kit in two different ways: By either using the plate with bi-adhesive strip, or the screw plate. These methods allow you to safely "fix" the BTNext PRO unit onto your helmet and to remove it at any time in order to recharge or store it.

### Plate with bi-adhesive strip

The Bi-adhesive plate is already assembled on the slide-in mounting kit. Clean the application area on the helmet surface, remove the bi-adhesive film and place the fixing plate on the left side of the helmet by keeping it contact with the surface for a few seconds.



### Screw Clamp
**Step 1.** Remove the bi-adhesive plate from the slide mount using the allen wrench too included in the box.



**Step 2.** Tighten the screw plate to the slide-in mounting kit with the two provided screws.
**Step 3.** Then, tighten more the two screws in order to firmly fix the clamp in place on the left side of the helmet.

If neccesary, you can use also the rubber plate in order to have more grip for the screw clamp. Just use the two short screw to fix the rubber plate on the slide-in mount and tighten the screw plate again.

## Fitting and removing your Midland BTNEXT PRO

The BTNEXT PRO can be easily fitted onto the helmet by sliding it downwards on the sliding mounting kit. BTNEXT PRO is maintained in position thanks to the fixing clip located on the upper section (A).
To detach the BTNEXT PRO, simply press the fixing clip and push the unit upwards.

**Lock**      A      **Unlock**

## Switching ON and OFF your Midland BTNEXT PRO

**Switching the unit on:**

Press and hold "Middle" button for approximately 3 seconds until the BLUE indicator lights.

**Switching the unit off:**

Press and hold both "Middle" and "Backward" buttons together for approximately 3 se-

**Here is an example of the buttons main functionality based on the mode you are on.**

| Mode | Forward (Left button) | Middle button | Rear (Right button) |
|---|---|---|---|
| Intercom | Open/close the intercom to the first rider | Open/close the intercom to the second rider | Open/close the intercom to the Third rider |
| Phone | Redial last number/accept or reject incoming call on "Vol+" | | Redial last number/accept or reject incoming call on "Vol-" |
| Phone (while music play) | Forward the song | Play/pause | Backward the song |
| FM Radio | Scan up | FM Radio On/off | Scan down |

conds until the RED indicator flashes 3 times, thus lessening the chances that you might turn off the unit accidentally (especially whilst wearing gloves).

## Operative "mode"
The BTNEXT PRO can operate in three main "mode": Intercom, Phone and FM Radio. The 3 multi function buttons can have different functionality depending on which mode the unit is at that moment.

› **In "Intercom mode"** the three buttons let you manage the Intercom communications between driver and passenger or bike to bike.
› **In "Phone mode"** you can manage your Bluetooth mobile phone to place/answer a phone call or to listen to the music or GPS App. announcement (in stereo mode). Please use your phone responsibly and safely.
› **In "FM Radio mode"** you can listen to your favourite radio station in stereo, seek for a specific radio station and save it (6 memory are available).

You can switch (toggle) from one mode to the other simply pressing  the Middle  button for 3 seconds.  A voice announcement will tell in which mode you are on.
The toggle sequence is the following:
› **Intercom mode (if another unit has been paired)**
› **FM Radio**
› **Phone mode (if a phone has been paired)**
Every time you turn on the unit, the default mode is the last used mode.
The Intercom mode and Phone mode are avalaible only if it was previously paired to another unit or to a phone.
If you need to know in which mode the unit currently is, just press the "Volume + " and "Volume –" button together. A voice announcement will tell you the current mode.

## Maximum Distance
You can reach 1.6 Km intercom distance if you are in line of sight without obstructions and interferences (the riders must be always in sight).

## How to pair two Midland BTNEXT PRO units
The two units supplied in the same Midland BTNEXT PRO box, are already paired and ready to use, this means you don't need to perform this procedure. The units are already

paired using the Middle button.
If the devices are not part of the same kit, or the units has been purchased separately, you need to first pair them in order to use them.

### To pair the Midland BTNEXT PRO to another Midland BTNEXT PRO unit
To pair the Midland BTNEXT PRO to another Midland BTNEXT PRO unit, you must first enter the setup mode:
1. Turn off the unit
2. Press and hold down the middle button about 7 sec., until the Red light is on permanently.
3. Now press  the Middle button for 3 seconds. The Blue and Red lights will flash.
4. Do the same procedure on the other unit. When successfully paired, each unit will have the Blue light on for one second and then go back to the setup mode (Red light always on).
5. Now the pairing procedure is complete, you just need to exit the setup mode before you can use the units.
6. Double click on the Middle button, the Red light will turn off and the Blue light will start flashing.
You can use now your Midland BTNEXT PRO

*Attention: remember to switch off all the other Bluetooth device that are not part of the pairing procedure, only the two devices involved in the pairing must be turned on.*

### How to use the Intercom with two units
To use the intercom feature, be sure that both units are turned on and correctly paired together.

### Manual activation
When in "Intercom Mode" press the Middle button on one of the two units in "Intercom" mode. Communication is enabled and remains active until you press again the middle button. The intercom need some seconds to activate, you will hear a beep tone when the intercom is open.

### Voice activation (VOX)
Simply say something, after some seconds the communication will be opened and will remain active for the time you are talking. If there is no conversation the intercom will be

1. Turn off the unit
2. Press and hold down the middle button about 7 sec., until the Red light is on permanently.
3. Now press one of the three buttons (Forward, Middle or Backward) for 3 seconds depending on which button you would like use to open the intercom to the other unit. The Blue and Red lights will flash.
4. Repeat the same procedure on the other unit, you don't need to use the same button, you can choose one of the three buttons not previously used.
5. When successfully paired, each unit will have the Blue light on for one second and then go back to the setup mode (Red light always on).
6. Now the unit is ready for another pairing procedure, and you can pair another Midland BTNEXT PRO unit following the same procedure, but using a different button.

If you don't have more devices to pair, you must exit the setup mode before you can use the units:

› Double click on the Middle button, the Red light will turn off and the Blue light will start flashing. You can use now your Midland BTNEXT PRO

**How to use the Intercom with more than two units**

To use the intercom feature, be sure that all the units are turned on and correctly paired together.

**Manual activation in Intercom mode**

When in "Intercom Mode" press the button corresponding to the unit you would like to communicate with. After some seconds the intercom communication will open. The communication remains active until you press again the same button. To quickly open the intercom to another person, just press the button corresponding to the other unit, the intercom will be automatically closed and the new connection will be open (see Table A).

**Voice activation (VOX)**

The voice activation feature can open the intercom only to the unit paired to the Middle button.

*Hint: this feature is very useful when you have a specific person that you like to talk to more often (for example your passenger). In this way you don't need to press a button to open the communication.*

**Unit already busy in a conversation**

If you try to open an intercom connection to another person that is already talking with some one else (or is in a middle of a phone conversation), you will hear a "busy" double beep tone. Just wait sometime and try again, maybe this time the "line" is not busy.
The person who is called, will be advised that someone is trying to call and will hear a voice announcement with the number of the button from which the request is coming.
In this way as soon as the first conversation is over, the person can easily contact the caller by opening the intercom of the specific button number (indicated by the voice announcement).



**Conference**
The "Conference" mode allows the simultaneously communication between 4 people or, if you pair a intercom device also on VOL-, up to 8 people (4 couples). You can decide to use the BTNext Pro in "one to one" communication up to 6 people ("classic" Intercom mode) or with 8 people (4 couples) conference intercom (Conference mode).

**How to use the conference mode**

First of all you need to pair all the units in a "chain" mode, second the "Conference" feature must be active on all the units paired.

**Pairing**

To use the conference mode you need to pair all the units in a "chain" configuration. The BWD button of the first unit must be paired to the FWD button of the second unit. The BWD button of the second unit must be paired to the FWD button of the third unit and so on, till the fourth!

The first and the last unit must not be paired together (the chain must stay open).
The unit number 1 can talk to the last unit (number 4) only "through" the unit number 2 and number 3. That means to have the conference with four people, all the unit must have the intercom open.

### Activate Conference mode:

In "Intercom Mode" with no active audio, keep pressed the FWD button for 7 sec. The voice announcement "Conference" will tell you that it is active.
When the Conference mode is active the bluetooth devices paired on Vol+ button are disconnected, the paring on CTRL button and the Universal Intercom are not available. Now only the paring on FWD and BWD buttons are available, together with the device paired on the "Vol -" button.

### Disable Conference mode:

In "Conference Mode" with no active audio, keep pressed the FWD button for 7 sec. The voice announcement "Intercom" will tell you that you are back to the "One to One" Intercom mode and the device connected to the "Vol +" is available again, together with the Phone, the pairing on CTRL button and the Universal Intercom.

### Conference mode 4 people

When the conference mode is active, it is possible to open the conference communication pressing both the FWD and BWD buttons. One click on the button will open the intercom communication, one click on the same button will close it. The two units that are in the middle of the chain (unit 2 and 3) must keep the intercom open on both FWD and BWD buttons to allow the full communication of the four units together.

### "One Click Talk" function

When the conference mode is active, is possible to open the conference communication to all the 4 users just in "one click". Press short the CTRL (middle) button and you will automatically open the conference to the four unit connected.

## Conference mode with one Bluetooth device on "VOL-"

When the conference mode is active the Bluetooth device connected on VOL- is still available, that mean you can listen to GPS street indication or answer your phone call without "brake" the Conference connection chain.

The audio from the VOL- button connection can be **"Private"** (not shared in the Conference) or **"Public"** (the audio is shared with conference).
**By default the setting of conference mode is "Private".**
When you are in "private" mode if you receive a phone call or the GPS talk, you are temporary disconnected from the Conference, but the other people can keep on talking to each other. As soon as the Phone call is over (or the GPS stop talking), you are automatically back to the Conference.
**Activate Public mode:** long press the "VOL-" button , you will here the voice "Public"
**Activate Private mode:** long press again the VOL- button, the voice will tell you "Private".

*Attention: the incoming phone call is always "private" even if you are in "public" mode.*

## Conference mode up to 8 people (4 couples)

To have 8 people conference you need to pair one intercom device also to the "VOL- " button and be sure you selected the "Public" option.

*Attention: The paring of the intercom device on VOL- must be as "Universal Intercom".*

By default the setting of conference mode is "Private", that mean the first time you press long the "VOL-" button, you will hear the voice "Public". In case you heare "Private" you need to press again "VOL-" long untill you hear the voice "Public" mode.

**How to pair an Intercom device on the "VOL-" button:**

› On the BTNext Pro go in "Setup mode", press the "VOL-" button for 3 sec. The Blue and Red Led lights will start flashing
› On the other device, follow the procedure to pair as an Universal Intercom

How to open the Conference for the "VOL-" unit
To open the conference from the BTNext Pro to the unit connected to the "VOL-", just press the FWD button long.
To open the conference from the other unit connected to the "VOL-", just use the command to open the Universal intercom connection.

The maximum distance of the device connected to the VOL- button is 10 mt, this is why is suitable only for Passenger.

## Talk 2 All - Universal Intercom with different brand unit.

Thanks to the "Talk2 All - Universal Intercom" feature it is now possible to pair your Midland BTNEXT PRO to a different brand intercom available on the market.
You can pair a maximum of two not Midland Intercom devices, one on the "Forward" button and the other one on the Backward button.

• On the Midland BTNEXT PRO enter the setup mode: (with the unit OFF press and hold down
  the Middle button about 7 sec. until the Red light is on permanently).
• Keep pressed the "Forward" button or "Backward" button for 7 seconds: the Red and Blu LED light will start flashing fast, then (while you still keep the button pressed) the Red and Blu LED lights will change to slow flashing. Now you can release the button.

Talk2All - Universal Intercom
Not Midland Unit

Passenger

Talk2All - Universal Intercom
Midland Unit paired as a phone

On the other intercom (not Midland brand) follow the procedure to pair to a phone, because the BTNEXT PRO is paired as a Phone.
If successfully paired the red/blue lights will stop flashing and the blu light will slowly flash instead.

*Attention: remember to switch OFF all the other Bluetooth devices during the pairing procedure, only the two devices involved in the pairing must be turned on.*

To open the "Universal Intercom" communication on the Midland BTNEXT PRO while you are in "Intercom Mode", press long (3 sec) the Forward button or "Backward" button (depending on wich button you used for pairing) . On the other intercom just press the phone redial or voice dial button.
Maybe it will be necessary to press the redial button two times, depending on the model of the not Midland intercom.

*Attention: In order to use the "Talk2All-Universal Intercom" feature the pairing on the other unit must be done as a phone. The other intercom (not Midland brand) will be able to be paired to a phone only if two phones are supported.*

*You can pair also a Midland unit as Talk2All, that means the pairing must be done as a phone (one unit use the Talk2All procedure and the other unit use the pairing to "Phone" procedure).*

## Compatibility with Midland BT line units

The BTNEXT PRO is compatible with BTX1 PRO, BTX2 PRO, BT Next Conference, BTX2 FM and BTX2 FM.
When paired the max distance of the intercom is defined from the lower possible.

The BTNEXT PRO is compatible with the previous line of Midland BT (BT Next, BTX2 and BTX2) only if updated to firmware version 2014 or later.

## Pairing the Midland BTNEXT PRO to Bluetooth devices

The Midland BTNEXT PRO unit can be paired to other Bluetooth devices, like Phone, GPS Navigator or PMR446 Radio with built-in or external Bluetooth (dongle). The pairing procedure must be done using the "Volume +" or the "Volume -" buttons.
› **Pairing to the "Volume +" button:** for Phone with music A2DP stereo, GPS Navigator with A2DP audio or external mono/Stereo A2DP dongle.
All devices paired to "Volume +" button has higher priority and will interrupt all the other communication (like Intercom, FM Radio and Music).
› **Pairing to the "Volume -" button:** for Phone with music A2DP stereo, GPS Navigator with A2DP audio or external mono/Stereo A2DP dongle.
All devices paired to "Volume -" button are always in active in background during the Intercom communication.

| VOL - Always in background | VOL + High Priority |
|---|---|
| › Phone (HFP/A2DP Stereo)<br>› GPS (HFP/A2DP Stereo)<br>› Dongle (HFP/A2DP Stereo) | › Phone (HFP/A2DP Stereo)<br>› GPS (HFP/A2DP Stereo)<br>› Dongle (HFP/A2DP Stereo) |

When a device is paired to the "Vol +" or "Vol –" buttons the "Phone" mode is activated.

### Background feature

The audio connection on any device paired on "Vol-" button, even if it is stereo, is always in background. In this way the Intercom communication will not be interrupted, for example, by the GPS's street indication or other audio source. You can decide if the audio from the "Vol -" connection is shared with other people when the intercom is open (public) or if it must be private (private).
To share the audio from "Vol -" with the intercom: long press the "Vol-" button the voice will tell you "**public**"
To keep the audio from "Vol -" private: long press the "Vol-" button again the voice will tell you "**private**"

*Attention: By default the audio is private*

The audio from "Vol -" has always lower priority against the Intercom, that means when the intercom is open the audio is lowered by default to 50%. You can change this setting using the BTUpdater PC Software

### Pairing with one or two phones

The cellular phone can be paired to the "Vol +" or to the "Vol –".

When a phone is paired to the "Vol +" or "Vol-" the "Phone" mode is activated.
An incoming call has always the higher priority, that means all other communications will be closed (Intercom, FM Radio, Music).
If another incoming call will arrive on the second phone,  an alert sound will notify it.

**WARNING!**
In order to have the best performance with your mobile phone, it is suggested to keep it as close as possible to your BT NEXT PRO unit, on the left side  of your body and in the upper pocket of your jacket if  it's possible.

### How to pair the Midland BTNEXT PRO to a Phone

To pair the Midland BTNEXT PRO to a Phone, you must first enter the setup mode:
1. Turn off the unit
2. Press and hold down the middle button about 7 sec., until the Red light is on permanently.
3. Now press for 3 seconds the **"Volume +" or "Volume -"** button, the Blue and Red lights will flash.
4. Enable the Bluetooth device search feature on your mobile phone
5. After some seconds, "Midland BTNEXT PRO" will be displayed on your mobile phone.

Follow the pairing procedure of your Phone. If a pin code is requested you must enter "0000" (four time zero).

When successfully paired, the Blue light of the unit will be on for one second and than the unit will exit the setup mode and switch to the working mode (the Blue light will start flashing).

You can use now your Midland BTNEXT PRO together with the Phone.

## How to use a Phone

After pairing your phone to the Midland BTNEXT PRO unit you must switch to the "Phone" mode in order to use it. Press the middle button until you hear "Phone" from the voice announcement. Now all the three main buttons are dedicated to the phone (see Table B)

## Answering a call

When you hear the phone ring, you can answer in two different ways:

*Vocally:*

Simply say one word just after the first ring to answer the call and start talking.

*Manually:*

Tap the "Forward" or "Backward" button and start talking.

## Rejecting a call

If you don't wish to answer, you can let the mobile phone ring or press the "Forward" or "Backward" button for 3 seconds (you will hear one audio confirmation tone).

## Making a call

There are several ways to make a call.

*To redial the last number:*

Phone on Vol+: Press"Forward"button for 3 seconds in order to redial the last number (you will hear one audio confirmation tone).

Phone on Vol-: Press"Backward"button for 3 seconds in order to redial the last number (you will hear one audio confirmation tone).

To make a voice call:

Phone on Vol+: Briefly press"Forward"button. If your mobile phone supports voice calls, you will be asked to speak the name of the contact you wish to call.

Phone on Vol-: Briefly press"Backward"button. If your mobile phone supports voice calls, you will be asked to speak the name of the contact you wish to call.

**Priority: Calls have a high priority, which means that all other communications are temporarily disabled when a call arrives.**

## Ending a call

There are several ways to end a call:
› Wait for the called person to end the call.
› Press the "Forward" button (you will hear an audio confirmation tone).
› Press "End" button on the mobile phone.

## Speed dial

Only for the phone paired on Vol+ is possible to store one phone number in the unit memory and use it when needed. You must first save the number using the "BT UPDATER" Pc software or the smartphone "BT SET-APP" application. Then when you are in phone mode, just press 7 sec. the "Forward" button.

| B-Phone mode | | | |
|---|---|---|---|
| **Mode** | **Forward button (Phone on Vol+)** | **Middle button** | **Backward button (Phone on Vol-)** |
| **Phone** | **Short press:** Voice dial /accept or close if it is in progress <br> **Long press:** redial last number/ or reject | **Long press:** Change mode | **Short press:** Voice dial /accept or close if it is in progress <br> **Long press:** redial last number/ or reject |
| **Phone** (when music is plaing and paired on "Vol +") | Short press: Forward the song | **Short press:** Play/pause <br> **Long press:** Change mode | **Short press:** Backward the song |

### Using the MP3 player feature of the mobile phone

The mobile phone, when paired on "Volume +" or "Volume -" can be used as stereo MP3 players. The Midland BTNEXT PRO device fully supports the A2DP and AVRCP proto-cols that enable you to listen to stereo music and remotely control your mobile phone's MP3 player. You can even use the buttons on the Midland BTNEXT PRO unit to control the following play options: Play, Pause, Forward and Backward the songs.
It is possible to control only one phone at the time. You can choose which phone to con-trol, pressing 3 sec. the VOL+ button:
You will hear the voice "Control on volume up" . Now you can control the phone paired on VOL+ button. If you want to switch the control to the other phone just press again for 3 sec. the VOL+ button and you will hear the voice "Control on volume down"

| Forward | Play/Pausa | Backward |

### Available controls:

› To play/pause music: click on the "Middle" button.
› To skip forward to the next song: press the "Forward" button.
› To skip backwards to the previous song: press the "Back" button.

*Priority: the music listening mode has the lowest priority. Therefore, it will always be disabled when another audio communication comes in.*

To chanage the priority behaviour you can use the "BT UPDATER" Pc Software or the smartphone "BT SET-APP" application

*.Attention: It is possible to control A2DP Stereo music only in "Phone Mode"*

### Music Share

Music Share is possible only from the phone paired on the VOL+ button. To start sharing your A2DP music with the passenger already paired on the middle button (maximum distance 10mt), you must press the "Backward" button long (3 sec.) while the music is playing. The passenger must be either in "Phone" or "Intercom" mode without any open audio. The passenger can only stop the music share pressing short the middle button (but cannot control the music). The driver can stop the music sharing just pressing again the "Backward" button long. With music share active you can not keep open the Intercom communication.

### GPS Navigator

The GPS Navigator can be paired using the "Volume+" or the "Volume-" button.
**Volume + button** (support for stereo A2DP audio and HFP mono)
All devices paired to "Vol +" button has higher priority and will interrupt all the other com-munication (like Intercom, and FM Radio).
**Volume - button** (support for stereo A2DP audio and HFP mono)

All devices paired on "Vol -" button are always active in background during the Intercom communication. You can decide if the audio from the "Vol -" connection is shared with other people when the intercom is open ("Public" feature on) or if it must be private ("Private" feature on). See the "Background" paragraph above.

### GPS Stereo (A2DP) voice announcement

Midland BTNEXT PRO support Stereo (A2DP) voice announcement from GPS Na-vigators or smartphone application on both Vol+ or Vol- connection. When connected on "Volume +" button, the GPS street voice announcements will interrupt all other communication. Only when connected on Vol- the GPS voice announcements are in backgroud.

### How to pair the Midland BTNEXT PRO to a GPS

In general it is possible to pair the Midland BTNEXT PRO to all the GPS for motorbike that support Bluetooth headset connection.
To pair the Midland BTNEXT PRO to a GPS, you must first enter the setup mode:
1. Turn off the unit

2. Press and hold down the "Middle" button about 7 sec., until the Red light is on permanently.
3. Now press firmly (3 sec) the "Volume +" or "Volume -" button, the Blue and Red lights will flash.
4. Enable the Bluetooth device search feature on your GPS
5. After some seconds, "Midland BTNEXT PRO" will be displayed on your GPS.
6. Follow the pairing procedure of your GPS. If a pin code is requested you must enter "0000" (four times zero).

When successfully paired, the Blue light of the unit will be on for one second and then the unit will exit the setup mode and switch to the working mode (the Blue light will start flashing).

You can now use your Midland BTNEXT PRO with the GPS for street voice announcement.

### Pairing to a PMR446 radio with integrated or external Bluetooth

The PMR446 Radio can be paired to the "Volume +" or "Volume -" button. If paired on "Volume -", the PMR446 radio is always in the background even when you talk on the intercom.

### Pairing procedure

› Turn off the unit
› Press and hold down the "Middle" button about 7 sec., until the Red light is on permanently.
› Now press firmly (3 sec) the "Vol +" or "Vol -" button, the Blue and Red light will flash.
› Follow now the pairing procedure explained on the manual of the transceiver itself

## How to listen to the FM Radio

The FM Radio receiver is integrated inside the unit. You just need to switch to the "FM Radio"

mode in order to use it.

Long press the middle button until you hear "FM radio" from the voice announcement. Now all the three main buttons are dedicated to the FM Radio (See Table C).

Press short the "Forward" or the "Backward" button to seek the FM Radio station.

When you press long the Forward or the Backward button, you can scan up or down the 6 recorded stations. A voice announcement will tell you the number of which memory you are entering.

To save the station you are listening to, press the Forward and Backward buttons together for 3 sec. You will hear a beep tone for confirmation.

The station is saved over the last recorded station used.

Thanks to the RDS system, the FM Radio will choose the strongest signal available for the radio station you like to listen. The RDS system is OFF by default, if needed you can toggle on/off the RDS pressing together the "Volume +" and "Volume – " buttons for 3 sec when the radio is on. A voice announcement will tell you the RDS status.

### How to Disable/Enable the FM Radio

By default the FM radio is on.

*Disabling:*

› Enter the "Setup" mode: turn off the unit and hold down the "Middle" button about 7 sec., until the Red light is on permanently.
› Press "Middle" and "Volume+" buttons together for 3 seconds. The blue LED will flash three times.
› Double click on the "Middle" button to exit the "Setup" mode and use the Midland BT-NEXT PRO

*Enabling:*

› Follow the same procedure up described; now the blue LED will flash once.

| C-Radio FM mode | | | |
|---|---|---|---|
| **Mode** | **Forward button** | **Middle button** | **Rear button** |
| FM Radio | **Short press:** seek station up<br>**Long press:** Scan recorded | **Short press:** On/off<br>**Long press:** Change mode | **Short press:** seek station up<br>**Long press:** Scan recorded |

To exit the "Setup" mode, double click the "Middle" button.

### FM Radio with intercom

When you are in "FM Radio" mode it is not possible to manually open the intercom, you can only open it using VOX feature (just talk) to the unit paired on the "Middle" button. To manually activate the intercom you must switch to "Intercom" mode.

## Wired audio input

Your Midland BTNEXT PRO can be connected to a wired audio source, like an iPod (or any other MP3 Player).

### Listening to music

To listen to music from the wired input, connect the audio source using the optional AUX cable. The volume buttons (Vol + and Vol -) can be used to adjust the volume of the wired audio source (but not independently from the Intercom Volume). The AGC system will automatically increase the volume on higher speed.

*Attention: never set the volume of the MP3 Player to the maximum possible. Normally the best level is about the 70% of the maximum.*

*Hint: We recommend that you perform a few tests adjusting the volume of your iPod/MP3 player so at the normal speed the Headset volume is suited to your needs. The AGC system will automatically increase the volume on higher speed, so you don't need the VOL+ or VOL- buttons to adjust it.*

### Enabling/disabling the wired input

If needed the wired input can be enabled or disabled:
Enabling/Disabling: Make a Long press (3 sec.) on the "Forward" and "Middle" buttons (you will hear one audio beep tone for enabling confirmation and two audio beep tones for disabling). This setting is rembered also after turning On/Off the unit.

### Wired audio in background

The audio from the wired connection can be in background to your Intercom or Phone communication. By default this option is ON. Please refer to the paragraph "Wired connection always in background" below to disable it.
Note that is not possible to have the wired audio source in background to the FM radio.

## Emergency Stop light

On the back of your BTX1 PRO mounting kit you have an ultra bright LED emergency stop light. Every time you make a full brake, the stop light will turn ON to give an extra alert to the drivers behind you. In case you need to turn it OFF temporarily (for example when you ride with a passenger), just press long "Backward" and "Forward" button together while in "Phone" or "Intercom" mode (a voice announcement will confirm the status). The unit will remember the last setting used, that mean you need to turn ON manually the stop light pressing again "Backward" and "Forward" button togheter.

Stop Light

*Attention: By default the stop light is OFF*

## Setup and special configurations

### Resetting all paired devices

Sometimes you may find it necessary to delete all the pairing references stored in the Midland BTNEXT PRO unit (reset operation).
To perform this operation you must first enter the setup mode:
› Turn off the unit
› Press and hold down the "Middle" button about 7 sec., until the Red light is on permanently.
› Then simultaneously press and hold down the "Volume +" and "Volume –" buttons for 3 seconds. The Blue Light will be lit on for 1 sec and then back to steady RED.
› Double click on the "Middle" button to exit the "Setup" mode and use the Midland BTNEXT PRO.
This procedure deletes all the paired Bluetooth devices stored in the memory and it is therefore possible to start a new "clean" pairing session.

*Attention: after resetting all the pairting, only the "FM Radio" mode wil be available.*

### Back to factory setting

Sometimes you may find it necessary to go back to the factory setting, to reset all the changes/setup already made and have a "clean" unit.

To perform this operation you must first enter the setup mode:
› Turn off the unit
› Press and hold down the "Middle" button about 7 sec., until the Red light is on permanently.
› Then simultaneously press and hold down all the three buttons "Forward"-"Middle"-"Backward" for 3 seconds. The Blue Light will be lit on for 1 sec and than back to steady RED.
› Double click on the "Middle" button to exit the "Setup" mode and use the Midland BTNEXT PRO

## Adjusting/ Disabling the VOX feature (Intercom and telephone)

The Intercom feature can be enabled both manually and vocally (VOX). The VOX activation is influenced by the helmet type, the background noise and therefore by the speed. For optimum results, it is possible to choose one of the following four microphone sensitivity levels: high, medium, low and very low. It is also possible to disable the VOX feature in order to activate the Intercom and phone call answering features in manual mode only.

## Adjusting the sensitivity of the (VOX)

To perform this operation you must first enter the setup mode:
1. Turn off the unit
2. Press and hold down the "Middle" button about 7 sec., until the Red light is on permanently.
3. Your Midland BTNEXT PRO is now in "Set up mode".
4. Press the "Backward" button shortly and the red light changes to a steady blue.
5. Now, press "Volume +" or "Volume -" to increase or reduce sensitivity. Every time you press the Volume buttons the RED light will flash for confirmation. When you reach the end of the upper and lower limit, the RED light will not flash.
6. Press again the "Backward" button shortly; the Blue light will flash several times, in order to let you know the selected sensitivity:
   One flash = VOX disabled
   Twice = low sensitivity
   3 times= normal sensitivity
   4 times= high sensitivity
   5 times = Highest sensitivity
   The light indicator is now back to steady RED ("Set up mode") and the changes are

confirmed
7. If needed, you can adjust again the sensitivity repeating the steps from point 1, otherwise exit the Setting mode by double clicking the "Middle" button. Once the red light turns off, the blue led starts blinking. Now you can use your Midland BTNEXT PRO

## Disabling the VOX feature (Intercom and telephone)

Follow all the procedure described in the previous steps and choose the option of only one flash (VOX disabled).

*Attention! If you disable the VOX feature, you will be able to answer incoming phone calls only by pressing the "Forward" button.*

## Wired connection always in background

This feature lets you keep the wired connection always on, even when the phone or the intercom is open (but not when you are in FM radio mode).
By default the Background feature is ON.

*Disabling*:
› Enter the "Setup" mode:
› Turn off the unit
› Press and hold down the "Middle" button about 7 sec., until the Red light is on permanently.
› Press the "Forward" and "Middle" button together for 3 seconds. The blue LED will flash three times.
› Double click on the "Middle" button to exit the "Setup" mode and use the BTNEXT PRO

*Enabling:*
Follow the same procedure up described; now the blue LED will flash once.
To exit the "Setup" mode, double click the "Middle" button.

## Setup and Firmware update

It is possible to configure and update the firmware of your Midland BTNEXT PRO using the USB connection to your PC. On the Midland web site www.midlandeurope.com in the Midland BTNEXT PRO page you can find the PC software and the new firmware updates if available.
ATTENTION DO NOT CONNNECT THE UNIT TO THE PC BEFORE you DOWN-LOAD AND INSTALL THE SOFTWARE

### Use at your own risk

The use of the device will impair your ability to hear other sounds and others around you. Listening to music or speaking on a telephone may prevent you from hearing others around you and distract you from riding safely. The use of such device while riding may endanger you and others, and its use, in some areas, could not be allowed.
Using this device at a high volume may result in permanent hearing loss.
If you experience ringing in your ear or any other hearing related pain, reduce the volume or discontinue using this device. With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing.
Please use this device at a safe volume level.

## Warranty

The warranty lasts 24 months for the main device and 6 months for the accessories (batteries, chargers, antennas, headsets, microphones).
For further information about the warranty, please visit
www.midlandeurope.com.

## European CE Notice Certification and Safety Approval Information

This product is CE marked according to the RTTE Directive 99/5/EC (from 13/06/2017, of Directive 2014/53/UE) and is free use in all the EU countries.
Users are not permitted to make any changes or modifications to the device.
Modifications which are not expressly approved by the producer invalidate the warranty card.
For further information, please go to our website: www.midlandeurope.com

- **INFORMAZIONE AGLI UTENTI**: i sensi dell'art. 13 del decreto legislativo 25 luglio 2005, n.151 "Attuazione delle Direttive 2002/95/CE, 2002/96/CE e 2003/108/CE, relative alla riduzione dell'uso di sostanze pericolose nelle apparecchiature elettriche ed elettroniche, nonché allo smaltimento dei rifiuti".

  Il simbolo del cassonetto barrato riportato sull'apparecchiatura indica che il prodotto alla fine della propria vita utile deve essere raccolto separatamente dagli altri rifiuti. L'utente dovrà, pertanto, conferire l'apparecchiatura giunta a fine vita agli idonei centri di raccolta differenziata dei rifiuti elettronici ed elettrotecnici, oppure riconsegnarla al rivenditore al momento dell'acquisto di una nuova apparecchiatura di tipo equivalente, in ragione di uno a uno. L'adeguata raccolta differenziata per l'avvio successivo dell'apparecchiatura dismessa al riciclaggio, al trattamento e allo smaltimento ambientalmente compatibile contribuisce ad evitare possibili effetti negativi sull'ambiente e sulla salute e favorisce il riciclo dei materiali di cui è composta l'apparecchiatura. Lo smaltimento abusivo del prodotto da parte dell'utente comporta l'applicazione delle sanzioni amministrative di cui al dlgs. n.22/1997 (articolo 50 e seguenti del dlgs. n.22/1997).

- All articles displaying this symbol on the body, packaging or instruction manual of same, must not be thrown away into normal disposal bins but brought to specialised waste disposal centres. Here, the various materials will be divided by characteristics and recycles, thus making an important contribution to environmental protection.

- Alle Artikel, die auf der Verpackung oder der Gebrauchanweisung dieses Symbol tragen, dürfen nicht in den normalen Mülltonnen entsorgt werden, sondern müssen an gesonderten Sammelstellen abgegeben werden. Dort werden die Materialien entsprechend ihrer Eigenschaften getrennt und, um einen Beitrag zum Umweltschutz zu liefern, wiederverwertet.

- Todos los artículos que exhiban este símbolo en el cuerpo del producto, en el embalaje o en el manual de instrucciones del mismo, no deben ser desechados junto a los residuos urbanos normales sino que deben ser depositados en los centros de recogida especializados. En estos centros, los materiales se dividirán en base a sus características y serán reciclados, para así poder contribuir de manera importante a la protección y conservación del medio ambiente.

- Tous les articles présentant ce symbole sur le corps, l'emballage ou le manuel d'utilisation de celui-ci ne doivent pas être jetés dans des poubelles normales mais être amenés dans des centres de traitement spécialisés. Là, les différents matériaux seront séparés par caractéristiques et recyclés, permettant ainsi de contribuer à la protection de l'environnement.

**CE** ♲ ⌷ ⌷ **RoHS Compliant**

Prodotto o importato da: **CTE INTERNATIONAL srl**
Via. R.Sevardi 7 42124 Reggio Emilia - Italia.

Prima dell'uso leggere attentamente le istruzioni.


Produced or imported by: **CTE INTERNATIONAL srl**
Via. R.Sevardi 7 42124 Reggio Emilia - Italy.

Read the instructions carefully before installation and use.


Vertrieb durch: **ALAN ELECTRONICS GmbH**
Daimlerstraße 1K - D-63303 Dreieich Deutschland.

Vor Benutzung Bedienungsanleitung beachten.


Importado por: **ALAN COMMUNICATIONS, SA**
C/Cobalt, 48 - 08940 Cornellà de Llobregat, Barcelona - España.

Antes de utilizar, lea atentamente el manual de uso.

| DO: | 7.1.4.4 |
|---|---|
| Rev: | 5 |
| Authorised on: | 02/02/2010 |
| By : | S. Peterlini |
| Signature | |

**EC Certificate of Conformity**

(to EC Directive 99/5 -2004/108- 2006/95/EC)

CE

DECLARATION OF CONFORMITY N° 2016092601

Manufacturer: C.T.E. International S.r.l.
Address: VIA SEVARDI 7 – ZONA INDUSTRIALE MANCASALE – 42124 REGGIO EMILIA
Products Name: **BT NEXT PRO**
Product Type: **BLUETOOTH HEADSET INTERCOM**
Brand : **MIDLAND**

The product described above is in conformity with the following Specifications based on sample testing:

| Item of 99/05/CE or 2004/108/EC | Standard | Title | Edition or date of issue |
|---|---|---|---|
| 3.1.a | EN 60065 :2002+A1:2006 +A11 :2008 +A2:2010+A12:2011 | Audio, video and similar electronic apparatus - Safety requirements | 2011 |
| 3.1a | EN 62479 | Assessment of the compliance of low power electronic and electrical equipment with the basic restrictions related to human exposure to electromagnetic fields (10 MHz to 300 GHz) IEC 62479:2010 (Modified) | 2010 |
| 3.1b | EN 301 489-1 | electromagnetic compatibility and Radio spectrum Matters (ERM); Electromagnetic compatibility (EMC) standard for radio equipment and services ; Part 1: common technical requirements | V1.9.2 |
| 3.1b | EN 301 489-17 | Electromagnetic compatibility and Radio spectrum Matters (ERM); Electromagnetic Compatibility (EMC) standard for radio equipment; Part 17: Specific conditions for Broadband Data Transmission Systems | V2.2.1 |
| 3.2 | EN 300 328 | Electromagnetic compatibility and Radio spectrum Matters (ERM); Wideband transmission systems; Data transmission equipment operating in the 2,4 GHz ISM band and using wide band modulation techniques; Harmonized EN covering essential requirements under article 3.2 of the R&TTE Directive | V1.8.1 |

*Supplementary information to the conformity assessment result on which the declaration is based:*
Conformity assessment procedures are referred to art. 10(4) linked with Annex III of Directive 1999/5/ec.
The test sample fullfils the requirements specified above, on the basis of test result and their evaluation.
The product herewith complies with the essential requirements of EC Directive 99/05/EC, 2004/108/EC and following implements and modifications, 2006/95/EC and following implements and modifications, 93/97/EC. Reference to any marking or other indication (e.g. on the product) is exhibited in attachment to this declaration.
Reggio Emilia, 26/09/2016

CTE International srl
Quality Assurance Responsible
Rebecca Bardella

# RTTE

**I / RSM**
Cte International Srl dichiara che il prodotto è conforme ai requisiti essenziali e alle disposizioni della Direttiva 1999/5/CE (dal 13/06/2017 alla Direttiva 2014/53/UE). La Dichiarazione di conformità si può scaricare dal sito **http://www.midlandeurope.com/it/pagina/10090-certifications**

**UK / CY / M**
Hereby Cte International Srl declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC(from 13/06/2017, of Directive 2014/53/UE). The declaration of conformity is available on the web site **http://www.midlandeurope.com/it/pagina/10090-certifications**

**A / D / CH / FL**
Hiermit erklärt Cte International Srl, dass das Produkt die grundlegenden Anforderungen und anderen relevanten Bestimmungen der Richtlinie 1999/5/EC erfüllt (ab dem 13.06.2017, erfüllt es die Auflagen der Richtlinie 2014/53/UE). Die Konformitätserklärung ist unter folgendem Link verfügbar: **http://www.midlandeurope.com/it/pagina/10090-certifications**

**E**
CTE International SRL. declara, bajo su responsabilidad, que este aparato cumple con lo dispuesto en la Directiva 99/05/CE, del Parlamento Europeo y del Consejo de 9 de marzo de 1999, transpuesta a la legislación española mediante el Real Decreto 1890/2000, de 20 de noviembre (desde el 13/06/2017 a la Directiva 2014/53/UE). La Declaración de Conformidad está disponible en **http://www.midlandeurope.com/it/pagina/10090-certifications**

**F / LUX / CH**
Par la présente Cte International Srl déclare que le modèle est conforme aux exigences essentielles et autres dispositions pertinentes de la directive 1999/5/EC (du 13/06/2017, de la Directive 2014/53/UE). La déclaration de conformité est disponible sur le site internet **http://www.midlandeurope.com/it/pagina/10090-certifications**

**P**
A CTE INTERNATIONAL declara que este aparelho cumpre com o disposto na Directiva 1999/5/CE do Parlamento Europeu e do Conselho de 9 de Março de 1999, transposta para a legislação nacional pelo Decreto-Lei n.º 192/2000, de 18 de Agosto (de 13/06/2017 este aparelho está em conformidade com a Directiva 2014/53/UE). A Declaração de Conformidade está disponível no sitio na Internet em **http://www.midlandeurope.com/it/pagina/10090-certifications**

**GR**
Με την παρών, η Cte International Srl δηλώνει οτι το όνομα του μοντέλου συμμορφώνεται ως προς τις βασικές απαιτήσεις και άλλες σχετικές διατάξεις του Κανονισμού 1999/5/EC (από 13/06/2017, θα συμμορφώνεται με τον Κανονισμό 2014/53/UE). Η δήλωση συμμόρφωσης είναι διαθέσιμη στην ιστοσελίδα **http://www.midlandeurope.com/it/pagina/10090-certifications**

**NL**
Hierbij verklaard CTE International Srl dat dit model (-naam) voldoet aan de essentiële eisen en andere relevante bepalingen van richtlijn 1999/5/EG (uit 13/06/2017, richtlijn 2014/53/UE). De verklaring van conformiteit is beschikbaar op de website **http://www.midlandeurope.com/it/pagina/10090-certifications**

**BE**
CTE INTERNATIONAL Srl verklaart dat het product overeenstemt met de voorschriften en andere bepalingen van de richtlijn 1999/5/EC (uit 13/06/2017, richtlijn 2014/53/UE). De conformiteitsverklaring is voorhanden op de website **http://www.midlandeurope.com/it/pagina/10090-certifications**

**PL**
CTE International Srl deklaruje, że ten model jest zgodny z wymaganiami zasadniczymi i innymi istotnymi postanowieniami Dyrektywy 1999/5/EC (OD 13/06/2017, Direktywy 2014/53/UE). Deklaracja Zgodności jest dostepna na stronie **http://www.midlandeurope.com/it/pagina/10090-certifications**

**RO**
Cte International Srl declara ca acest model este in conformitate cu cerintele esentiale si alte prevederi ale Directivei 1999/5/EC (din 13/06/2017, ale Directivei 2014/53/UE). Declaratia de confomitate este disponibila si pe site-ul **http://www.midlandeurope.com/it/pagina/10090-certifications**.

**BG**
С настоящото CTE international Srl декларира, че продукта е в съответствие с основните изисквания и съответните модификации на Директива 1999/5/EC (от 13/06/2017, Директива 2014/53/UE). Декларацията за съвместимост е налична на сайта: **http://www.midlandeurope.com/it/pagina/10090-certifications**

**N**
CTE INTERNATIONAL Srl erklærer at produktet er i overensstemmelse med de viktigste kravene og andre relevante betingelser i Direktivet 1999/5/EF (fra 13/06/2017, direktiv 2014/53/UE). Samsvarserklæringen finnes tilgjengelig på nettstedet **http://www.midlandeurope.com/it/pagina/10090-certifications**

**DK**
Hermed erklærer Cte International Srl , at dette apperat er i overensstemmelse med kravene og andre relevante bestemmelser i direktiv 1999/5 / EF (fra 13/06/2017, direktiv 2014/53/UE). Overensstemmelseserklæringen findes på webstedet **http://www.midlandeurope.com/it/pagina/10090-certifications**

**SE**
CTE INTERNATIONAL Srl förkunnar att produkten överensstämmer med de väsentliga kraven och övriga bestämmelser i direktiv 1999/5/EG (FRÅN 13/06/2017 direktiv 2014/53/EU). Denna försäkran om överensstämmelse finns på webbplatsen **http://www.midlandeurope.com/it/pagina/10090-certifications**

**FIN**
CTE INTERNATIONAL Srl vakuuttaa, että tuote täyttää direktiivin 1999/5/EY asettamat olennaiset vaatimukset ja muut asiaa koskevat määräykset (FROM 13/06/2017 direktiivi 2014/53/UE). Vaatimuksenmukaisuusvakuutus on saatavilla **http://www.midlandeurope.com/it/pagina/10090-certifications** –**verkkosivuilla.**

**HR**
Cte International Srl ovime izjavljuje da je ime ovog modela u suglasnosti sa bitnim zahtjevima te ostalim relevantnim odredbama Propisa 1999/5/EC (OD 06.13.2017, Direktiva 2014/53/EU). Ova Izjava o suglasnosti je dostupna na web stranici **http://www.midlandeurope.com/it/pagina/10090-certifications**.

**ES**
Käesolevaga kinnitab Cte International Srl selle mudeli vastavust direktiivi 1999/5/EC olulistele nõuetele ja teistele asjakohastele sätetele (Alates 2017/06/13, direktiivi 2014/53/UE). Vastavusdeklaratsioon on kättesaadav veebilehel **http://www.midlandeurope.com/it/pagina/10090-certifications**

**LT**
CTE International patvirtina, kad šis modelis atitinka visus esminius Direktyvos 1999/5/EC bei su ja susijusių dokumentų reikalavinus (IŠ 13.06.2017, Direktyva 2014/53 / UE). Atitikties deklaracija yra pateikiama internetinėje svetainėje **http://www.midlandeurope.com/it/pagina/10090-certifications**

**LV**
CTE INTERNATIONAL Srl deklarē, ka produkts atbilst pamatprasībām un citiem ar to saistītajiem Direktīvas 1999/5/EK noteikumiem (NO 13.06.2017, Direktīvu 2014/53 / UE). Atbilstības deklarācija ir pieejama mājas lapā: **http://www.midlandeurope.com/it/pagina/10090-certifications**

**SK**
Týmto Cte International Srl prehlasuje, že tento názov model je v zhode so základnými požiadavkami a ďalšími príslušnými ustanoveniami smernice 1999/5 / ES (od 13.06.2017, smernice 2014/53 /UE). Vyhlásenie o zhode je k dispozícii na webových stránkach **http://www.midlandeurope.com/it/pagina/10090-certifications**

**SL**
Cte International Srl deklarira da je ta model skladen z bistvenimi zahtevami in drugimi relevantnimi določili EU direktive 1999/5/EC (s 13.06.2017, Direktive 2014/53/UE). Deklaracija o skladnosti je na voljo na spletni strani **http://www.midlandeurope.com/it/pagina/10090-certifications**

**CZ**
CTE INTERNATIONAL SRL prohlašuje, že výrobek je v souladu s 1999/5 / ES (od 06.13.2017, směrnice 2014/53/UE). Prohlášení o shodě je k dispozici na webových stránkách **http://www.midlandeurope.com/it/pagina/10090-certifications**

**H**
Mi, a CTE International Srl. saját felelősségre kijelentjük, hogy ezen elnevezésű termék megfelel az 1999/5/EC alapvető követelményeinek és egyéb releváns előírásoknak (által 2017/13/06 irányelv 2014/53 / UE). A megfelelőségi nyilatkozat elérhető weboldalunkon a **http://www.midlandeurope.com/it/pagina/10090-certifications** címen.

**SAR**
**I / RSM**
Importante: L'apparato deve essere utilizzato ad una distanza superiore a 5 cm dal corpo
**UK / CY / IRL/ M**
Important: The equipment must be used at least 5cm away from the bodyof use
**A / D / CH / FL**
Wichtig: Bei Verwendung des Gerätes muss ein Abstand von mehr als 5 cm zum Körper eingehalten werden.
**BE**
Belangrijk: De apparatuur moet gebruikt worden op een afstand van het lichaam die groter is dan 5cm
**BG**
ВАЖНО: Оборудването трябва да се използва на дистанция не по-малка от 5 см от тялото.
**CZ**
Důležité: Zařízení nesmí být používáno ve vzdálenosti méně než 5 cm od těla.
**DK**
Vigtigt: Udstyret skal skal være mindst 5cm fra kroppen under anvendelse
**E**
El equipo debe usarse a una distancia superior a 5cm del cuerpo.
**EST**
Märkus: Seade tuleb kasutada kaugemal kui 5cm kehast

**F / LUX / CH**
Important: l'appareil doit être utilisé à une distance supérieure à 5cm du corps.
**FIN**
Tärkeää: Laitetta on käytettävä etäisyydellä yli 5cm kehosta
**GR**
Σημαντικό: Ο εξοπλισμός θα πρέπει να χρησιμοποιείται σε απόσταση μεγαλύτερη των 5cm από το σώμα σας.
**HR**
Važno: Oprema se mora koristiti na udaljenosti većoj od 5 cm od tijela
**HU**
Fontos! Használat közben győződjön meg arról, hogy az eszköz legalább 5cm-re a testétől van.
**IS**
Búnaðurinn verður að nota í fjarlægð sem er meiri en 5cm úr líkamanum
**LT**
SVARBU: Įranga turi būti naudojama ne mažiau kaip 5cm atstumu nuo kūno.
**LV**
Aparāts jāizmanto attālumā vairāk nekā 5 cm no organisma
**N**
Viktig: Apparatet må brukes i en avstand på mer enn 5cm fra kroppen
**NL**
Belangrijk: Het apparaat moet op een afstand van minimaal 5 cm van het lichaam gebruikt worden.

**P**
Importante: O equipamento tem de ser usado a uma distância do corpo superior a 5cm.
**PL**
Uwaga: Urządzenie podczas pracy nie może znajdować się bliżej niż 5cm od ciała.
**RO**
Important: produsul trebuie utilizat la o distanta mai mare de 5cm fata de corp.
**SE**
Viktigt: Apparaten måste användas på ett avstånd av mer än 5 cm från kroppen
**SK**
Dôležité: Pri použití prístroja musí byť dodržaná minimálna vzdialenosť od tela 5 cm!
**SL**
Pomembno: Napravo se mora uporabljati vsaj 5 cm oddaljeno od človeškega telesa